

## MAINTENANCE

- DO NOT place the device near heat, fire or electrical sources.
- DO NOT place the device in standing water, under running water, in the dishwasher.
- DO NOT use product in a manner inconsistent with its labeling.
- DO NOT place where it can fall and damage property.
- DO NOT place where it can leak and damage surfaces.
- Keep out of reach of children and pets.
- We are not responsible for damage or injury caused by incorrect assembly or installation.
- Batteries - mercury/lead/cadmium

## TROUBLESHOOTING

If the device does not turn on:

- Check that the batteries are inserted in the correct orientation.

If the device does not dispense properly or does not dispense at all:

- Confirm that the device reservoir does not need to be refilled.
- Check to see if mister is standing in water. If so, the unit may no longer function, however, try removing the battery door, wiping and drying the interior thoroughly, then reinserting the batteries.
- The Spritz'n Clean Ultrasonic Mister automatically shuts off after 30 seconds. If liquid stops dispensing when cover is open, close cover and reopen device.

If liquid is dispensing unintentionally:

- Check to see that the reservoir plug is firmly pressed into the reservoir fill hole.
- Check to see that the reservoir is securely placed in the reservoir well.

## CAUTION

Use only Spritz'n Clean Tech Clean Cleansing Mist. Other types of cleaning liquid may lead to malfunction or damage to electronic device.

The Spritz'n Clean Tech Clean Cleansing Mist is intended for tech devices screens only. Do not ingest solution or bring into contact with your eyes.



# Spritz'n Clean™

Say goodbye to smudges, smears and finger prints. Introducing the Spritz'n Clean LCD Cleaning System. It combines the power of an ultrasonic mister, deionized cleansing formula and a MicroChamois. Together they leave the surface of your device clean, buffed and sparkling like new.

- Ultra-Slim and lightweight design
- Refillable reservoir
- Easy sliding power cover
- Conveniently sized to easily fit in your pocket, purse or backpack.



### Tech Clean Cleansing Mist

- 2 oz. refill bottle
- Alcohol & solvent free
- Streak free
- Safe and effective
- Environmentally Friendly

2oz. Refill \$9.95

### MicroChamois Cleaning Cloth

- Treated to trap and eliminate daily grime buildup.
- Washable & reusable
- Optical grade material

2-Pack \$9.95

Questions? Comments? [spritzn.com](http://spritzn.com)

1000081


MidCo LLC | 9604 NE 126th Avenue, Vancouver, WA 98682  
Patent Pending

TO ORDER  
REFILLS:

[spritzn.com](http://spritzn.com)



FRONT



BACK


## A: HOW TO SET UP SPRITZ'N CLEAN




1. Open battery compartment on mister back.



2. Insert 4 - AAA batteries as pictured. Look for the + & -.



3. Close the battery compartment firmly.



4. Pull reservoir latch downward to release reservoir cover.



5. Lift reservoir cover up to expose reservoir.



6. Lift reservoir plug



7. Fill reservoir with Spritz'n Clean Tech Clean cleansing mist.



8. Press reservoir plug firmly to secure an airtight seal.



9. Close reservoir cover.




10. Slide power cover downward to test unit. Power indicator should illuminate and ultrasonic mist should begin.




11. Slide power cover upward to shut unit off.

## B: HOW TO USE




1. Hold the Spritz'n Clean unit about 3" - 4" from surface. Slide power cover downward.



2. Spritz in an up and down motion for 10 seconds.



3. Slide power cover upward to shut unit off.



4. Let cleansing mist rest on screen for 10 seconds.



5. Wipe surface with the MicroChamoï cleansing cloth.



6. Store Spritz'n Clean in carry bag.